


4 01 A


Bottono Ø16 mm. - Supporto per pannelli
"Bottono" - Panel hanger Ø16 mm.



BT165	NKS	4	8032611951442
BT166	CR	4	8032611951459

4 01 B


Bottono Ø16 mm. - Supporto per pannelli con rosetta
"Bottono" - Panel hanger Ø16 mm. with washer



BT165R	NKS	4	8032611952432
BT166R	CR	4	8032611952449

4 01 C


Bottono Ø20 mm. - Supporto per pannelli
"Bottono" - Panel hanger Ø20 mm.



BT205	NKS	4	8032611953514
BT206	CR	4	8032611953521

4 01 D

Bottono Ø20 mm. - Supporto per pannelli con rosetta
"Bottono" - Panel hanger Ø20 mm. with washer




BT205R	NKS	4	8032611953538
BT206R	CR	4	8032611953545

4 02 A

Ferma pannelli frontale corto Ø16 per 7 mm.
7 mm. Ø16 short front wall panel hanger


Utilizzabile anche con il sistema magnetico piccolo
Can be used with little magnetic system



FP16075FCT	NKS	10	8032611954368
FP16076FCT	CR	10	8032611954375

4 02 B

Ferma pannelli frontale corto Ø16 per 7 mm. con rosetta
7 mm. Ø16 short front wall panel hanger with washer




FP16075FCRT	NKS	10	8032611954382
FP16076FCRT	CR	10	8032611954399

4 02 C

Ferma pannelli frontale Ø16 per 7 mm. con rosetta
7 mm. Ø16 front wall panel hanger with washer

Disponibile anche nella versione "easy lock"
(rif. 413B)
Also available in the "easy lock" version
(rif. 413B)



FP16075FT	NKS	10	8032611954405
FP16076FT	CR	10	8032611954412